



RISE & SHINE

REMOTE CONTROL



OFF Turns off the light in any status.

ON Turns on the light in any status no matter if it is day or night.

Add brightness by 10% each time you press this button. Max brightness will not surpass the power you preset from factory. For example, if you preset 13000lm as max brightness, it will not surpass that number.


Reduce brightness by 10% each time each time you press this button.

After you press this button, brightness will become half of the preset lumens, without affecting time control schedules. For example, if you preset 13000lm as max brightness, after you press this its brightness will become 50% that means 6500lm, and work mode will follow the work mode you setted, brightness will be 6500lm unless you press other work mode.


If you press this button, the brightness will go back to 100% lumens. Unless you have selected a work mode that is pre-programmed, for example only be at 40% brightness, then the brightness will increase to this level.

Do not use or press this button.


Back to factory setting




Mode 1:
30% brightness +
motion detection till
dawn



Mode 2:
5 hours 100%
Brightness + 30%
brightness with
motion detection till
dawn



Mode 3:
5 hours 100%
brightness + 4 hours
30% brightness +
70% brightness till
dawn



Mode 4:
100% output all the
time